Photo 101 Setting up a new camera

Orleans Photo Club 2023-09-09





Chris.Taylor@opcug.ca

Shiny new camera

- Plethora of configuration options in modern cameras
- Get the basic settings you want right at the start



A	f Controls	J
a	👔 Customize 🚺 menu	
-	f2 Custom control assignment	
	f3OK button	
Ÿ	#4 Shutter spd & aperture lock	
T	f5Customize command dials	
Ľ	f6 Release button to use dial	0FF
⊪∕	f7Reverse indicators	-0+
	g Customize i menu	

f1Cu	stomize 🚺 menu 📘 🗖
E	Choose image area
QUAL	Image quality
SIZE	Image size
2	Exposure compensation
ISO	ISO sensitivity settings
WB	White balance
	Set Picture Control

🖉 Options That Can Be Assigned to the i. Menu				
 Choose image area Image quality Image size Exposure compensation ISO sensitivity settings White balance Set Picture Control Color space Active D-Lighting Long exposure NR High ISO NR Metering Flash mode 	 Flash compensation Focus mode AF-area mode Vibration reduction Auto bracketing Multiple exposure HDR (high dynamic range) Silent photography Release mode Custom control assignment Exposure delay mode 	 Shutter type Apply settings to live view Split-screen display zoom Peaking highlights Monitor/viewfinder brightness Bluetooth connection Wi-Fi connection 		

First things first

Get complete manual from manufacturer's website

- much more info than normally included in the box even with pro-level cameras
- browse entire manual so you know what's possible
- If a used camera, reset all settings to factory defaults
 - never know how previous owner had things configured
- When first turned on, typically prompted for
 - language: menus can be in a variety of languages
 - date/time & time zone
- Update firmware (check manufacturer's website)
 - bug fixes and enhanced features



Second things second

- Format memory cards in-camera
 - not always required, but always recommended
- Set file format
 - RAW, JPEG, or both
- Set image size and quality
 - set to maximum: offers most flexibility
- Adjust viewfinder diopter
 - make sure everything in the viewfinder is sharp
- Adjust screen/EVF brightness
 - default may be fine
 - know how to adjust for different lighting conditions



More second things

- Turn off beeps that might
 - annoy other people
 - scare off wildlife
- Disable ability to take photos without a memory card to avoid;
 - forget to put card back in camera
 - shoot all day
 - discover you have no images!
- Set colour space (doesn't affect RAW format)
 - sRGB most appropriate for general sharing on email, the web, etc.
 - Adobe RGB more appropriate for high-end printing



Digging down a bit deeper

Set back-button focus

- decouples focus from the shutter-release button
- even if you don't think it is a good idea, try it for a week
- https://photographylife.com/back-button-focus
- Set autofocus mode
 - most cameras allow you to choose autofocus options such as *single-point*, *matrix*, *continuous*, *subject tracking*, *face/eye detect*, etc.
- Set release mode
 - single-shot vs. burst mode & frames per second
- Set shooting mode
 - aperture-priority automatic, shutter priority automatic, manual, auto, program





Extras

Copyright info

- many cameras can embed in metadata
- not a panacea
- might help get a lost camera returned
- Change generic file name prefix (IMG, DSC,...)
 - your initials, e.g. CJT_1324.JPG
 - camera identifier, e.g. NZ6_5436.NEF
- Replace strap
 - treat yourself to a comfortable and useful strap
- Spare memory cards and batteries

